



PLANT STRUCTURE EAST ELEVATION
SCALE: 1/8" = 1'-0"

PLANT STRUCTURE NORTH ELEVATION
SCALE: 1/8" = 1'-0"



OFFICE EAST ELEVATION
SCALE: 1/4" = 1'-0"

OFFICE NORTH ELEVATION
SCALE: 1/4" = 1'-0"